

Easy maintenance just by setting

AUTO HEAD CLEANER



- Automates the processes from cleaning to operation checks
- Maintains quality through various inspections and data management



Specifications

Heads	RH20, RH08, RH02	
Cleaning method	Air cleaning	
Cleaning period	13 minutes ^{*2}	
Inspection time	18 minutes ^{*2}	
Head cleaning interval	Every month (Every 700 hours)	
Size (L x W x H)	430 x 860 x 1,470 mm	
Weight	190 kg	
Power supply	3-phase AC200 to 230 V ±10V (50/60 Hz)	
Air supply	0.4 MPa	
Air consumption	Cleaning: 85 L/min (ANR)	Collection blowing: 145 L/min (ANR)

^{*1} The time is for when cleaning RH20 heads.

^{*2} The time is for when inspecting all the inspection items on RH20 heads.

FUJI CORPORATION

19 Chausuyama, Yamamachi, Chiryu, Aichi 472-8686 Japan

Tel: +81 566 81 2110

Fax: +81 566 83 1140

- The contents of this catalog are subject to change without notice due to constant product development.

- The information in this catalog is current as of December, 2020.

© 2020 FUJI CORPORATION. All Rights Reserved.